



Reference project/application



Extraction solution for occurring dust
in herbal preparations/mixing



Situation/challenge

- Herb powders are weighed and mixed at two workstations
- Dust contamination
- Some preparations cause employees to sneeze
- Increased cleaning effort



Solution

- Absident extraction arms with suction hood each mounted on the work table
- Utilization of a mobile dust collector ASD 200.1 between the two work tables
- Filtration system used as central extraction for both workplaces
- Suction power is regulated by keeping the vacuum constant



User benefits

- Only low suction power required – therefore no noise pollution
- Clean workplaces
- Health problems (sneezing) among employees have completely disappeared

